Selection of Chroma

Written by YingLong Friday, 06 October 2006 11:29 - Last Updated Friday, 17 September 2010 17:01

3. Selection of Chroma

Chroma is the percentage taken up in the workfloor of Diamond.

Select high chroma in the case of coarse granularity, coarse grinding requires the high efficiency, not Resinoid binder grinding tools ordinarily select chroma between 75-100%.

Metalic binder grinding tools ordinarily select chroma between 75-100%.

The relationship between Diamond chroma and content
Granularity
Content (carat□ cm3)
Diamond volume in the Diamond floor
50
2.2
12.5%
75
3.3
18.75%

Selection of Chroma

Written by YingLong Friday, 06 October 2006 11:29 - Last Updated Friday, 17 September 2010 17:01

100

4.4

25%